


A20-F

Auxiliary Power Unit (APU) Kontrol Box



A20-F REMOTE COMMAND CONTROL UNIT



- It is used to remote control APU.
- Positioning the vehicle by driver, thanks to the information screen on it, it enables to get access to all the data on APU.
- Control unit gives opportunity to activate-cancel APU system, to activate-cancel air conditioning system.
- It is designed as per IP67 Standards.
- It is conformant to MIL-STD-810G and MIL-STD-461E/F standards.

Dimensions (WidthxLengthxHeight)	45mmx155mmx85mm ±5
Weight	0,48 kg ±0.1
Communication Protocol	CANBUS J1939
Operating Voltage	24 VDC

1.	ON / OFF: APU on / off switch.	6.	EMERGENCY SHUTDOWN: When corresponding button is pressed APU operation is immediately blocked.
2.	AIR CONDITIONER ON/OFF: It is the button to switch on and off the air conditioning system.	7.	APU ON: Occasions and LED colours; Glow-Yellow, During Normal Operation-Green, Stop-Yellow, When Engine is Off-Red, Engine Does Not Start-Red
3.	CIT: When relevant button is pushed CIT test is made, when cancel button is pushed for 5 seconds this process is cancelled.	8.	AIR CONDITIONER ON: It is the led showing activeness status of air conditioner.
4.	CANCEL: When corresponding button is pressed, it exits constant screen. When BIT button is pushed for 5 seconds this action is cancelled.	9.	CIT: When test fails CIT led glows in red. When cancel button is pushed the led dims out.
5.	UPWARDS MENU BUTTON: When it is pressed error list is displayed. DOWNWARDS MENU BUTTON: When it is pressed, moves between pages.	10.	ERROR: If there is any error in the system led glows in red. When cancel button is pushed led dims out.